
# vtech

# Quick start guide



The Heart Beat sound tile was created by Larabadeu, and is used under the Creative Commons license. The Crickets At Night sound file was created by Mike Koenig, and is used under the Creative Commons license. The Stream Noise sound file was created by Caroline Ford, and is used under the Creative Commons license. The Background Noise sound file was created by Caroline Ford, and is used under the Creative Commons license,

ower requirements	Parent unit: 3.8V 2100mAh, Li-ion battery Baby unit power adapter: Output: 5V DC @ 1A Parent unit power adapter: Output: 5V DC @ 1A
effective range	Actual operating range may vary according to environmental conditions at the time of use.
CD	5" Colour LCD (WQVGA 480x272 pixel)
pannels	32
ransmit frequency	Baby unit: 2405 - 2475 MHz Parent unit: 2405 - 2475 MHz Waximum power used by the transmitter: 0.10W (100mW)

Crystal controlled PLL synthesizer

Zoom

### **IECHNICAL SPECIFICATIONS**

Press  $\oplus$  to zoom in or out.

requency control

### **IMPORTANT SAFETY INSTRUCTIONS**

The applied nameplate is located at the bottom of the baby When using your equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock

- and injury, including the following: Follow all warnings and instructions marked on the
- Adult setup is required 3. CAUTION: Do not install the baby unit at a height above
- 4. This product is intended as an aid. This product is not a substitute for adult supervision of the infant. Supervising the infant is the responsibility of the parent or carer.
- This product is not intended for use as a medical monitor. . Do not use this product near water, for example, near to bath, sink, swimming pool or shower
- 7. CAUTION: Use only the battery provided. There may be a risk of explosion if a wrong type of battery is used for the parent unit. The battery cannot be subjected to high or low extreme temperature and low air pressure at high altitude during use, storage or transportation. Disposal of battery into fire or a hor oven, or mechanically crushing or cutting or the battery can result in an explosion. Leaving the battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid of gas. Battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas. Dispose of used battery according to the instructions.
- Use only the adaptors included with this product Incorrect adaptor polarity or voltage can seriously

damage the product.

Power adaptor information: Output: 5V DC 1A
Ten Pao Industrial Co.,Ltd.
Model: S005BNV0500100(EU); S005BNB0500100(UK).

Vtech Telecommunications LTD Model: VT05EEU05100 (EU); VT05EUK05100 (UK)

Rechargeable battery information: Li-ion battery, 3.8V 2100mAh Zhongshan Tianmao Battery Co., Ltd. Model Number: BP1763 The power adaptors are intended to be correctly oriented

- in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet. For pluggable equipment, the socket-outlet should be installed near the equipment and should be easily
- Unplug this product from the wall outlet before cleaning Oo not use liquid or aerosol cleaners. Use a damp cloth for
- 12. Do not cut off the power adaptors to replace them with other plugs, as this causes a hazardous situation. 13. Do not allow anything to rest on the power cords. Do not

install this product where the cords may be walked on or

- 14. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home,
- consult your dealer or local power company. 15. Do not overload wall outlets or use an extension cord. 16. Do not place this product on an unstable table, shelf, stand
- or other unstable surfaces. 17. This product should not be placed in any area where proper ventilation is not provided. Slots and openings in the back or bottom of this product are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat

- . Never push objects of any kind into this product through the slots because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.
- 19. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility.

  Opening or removing parts of the product other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the product is subsequently
- . You should test the sound reception every time you turn on the units or move one of the components
- Periodically examine all components for damage.
- There is a very low risk of privacy loss when using certain electronic devices, such as baby monitors, cordless telephones, etc. To protect your privacy, make sure the product has never been used before purchase, reset the baby monitor periodically by powering off and then powering on the units, and power off the baby monitor if you will not use it for some time. if you will not use it for some time. Children should be supervised to ensure that they do not play with the product.
- The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their

### SAVE THESE INSTRUCTIONS

### Use and store the product at a temperature between 0°C

- Do not expose the product to extreme cold, heat or direct sunlight. Do not put the product close to a heating source. Batteries should not be exposed to excessive heat such as bright sunshine or fire.
- Warning—Strangulation Hazard— Warning—Strangulation Hazard—
  Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3 ft (0.9 m) away). Do not remove this tag.

  Never place the baby unit(s) inside the baby's Never place the baby unit(s) inside the baby's
- or parent unit with anything such as a towel or a blanket. Other electronic products may cause interference with your baby monitor. Try installing your baby monitor as far away from these electronic devices as possible: wireless routers, radios, cellular telephones, intercoms, room monitors, televisions, personal computers, kitchen appliances and cordless telephones.

cot or playpen. Never cover the baby unit(s)

Precautions for users of implanted cardiac pacemakers Cardiac pacemakers (applies only to digital cordless devices): Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the nterference between portable wireless devices and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicians that:

### Pacemaker patients

Should keep wireless devices at least six inches from the Should NOT place wireless devices directly over the

pacemaker, such as in a breast pocket, when it is turned ON. WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless devices.

### Electromagnetic fields (EMF)

This VTech product complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user's manual, the product is safe to be used based on scientific evidence available today


# -----


# CONNECT THE BABY MONITOR

WHAT'S IN THE BOX


### **■**NOTES


- The rechargeable battery in the parent unit is built-in.
- Use only the power adapters supplied with this product Make sure the baby monitor is not connected to a switch-controlled electric outlet.
- Connect the power adapters in a vertical or floor mount position only. The adapters' prongs are not designed to hold the weight of baby monitor, so do not connect them to any ceiling, under-the-table, or cabinet outlets. Otherwise, the adapters may not properly connect to the outlets.
- Make sure the parent unit, the baby units and the power adapter cords are out of reach of children.





# POSITIONING THE BABY MONITOR





• The default volume of your parent unit is level 4, and the maximum volume is level 7. If you experience feedback from your baby nonitor while positioning

Make sure your baby unit and parent unit are more than 3 feet (1 metre) apart, OR

Lower the volume of your parent unit.

# 4 STATUS CHECK

Once you power on both your baby unit and parent unit, your parent unit displays image from the baby unit, and the **LINK** LED light turns on

The **ON** LED light of baby unit turns on.



Turn on/off temperature alert tone.

whenever the room temperature

outside of the set temperature range.

detected by the baby unit falls

• Set the minimum temperature.

· Set the maximum temperature.

Set temperature display in

Set sound activation on or off.

of no sound detection.

turn on for 10 seconds.

When it is on, and the baby uni

a sound is detected, the parent unit screen and speaker turns on

detects no sound, the parent unit

automatically, and you can see and hear your baby. The parent unit will

When the parent unit screen is off and it receives alerts, for example, link lost between parent unit and

baby unit, or battery is low, the

parent unit screen and speaker will

then furn off again after 50 seconds

screen stays off to save power. Once

**ON/OFF** Turn on/off sound activation

Set the parent unit to beeps

# Basic operation - Parent unit


### Adjust speaker volume

Press ● VOL / VOL ● to adjust your parent unit speaker volume.



### Talk to your baby unit

Press and hold TALK and speak to your parent unit. Your voice is transmitted to talking and hear your baby again.



### Press and hold LCD ON/OFF to switch off

baby unit.

Turn off the screen

the baby unit. Release **TALK** when finish



the screen. You can still hear sound from the

• Press any keys on the parent unit to turn on the screen again.

### Use the menu

Press MENU to enter the menu, choose a menu item, or save a setting. You can use the parent unit for advanced settings or operations, such as to play or stop the baby unit lullaby, or to adjust the baby unit sound sensitivity.

While in the menu:

- Press MENU select an item, or to save a setting.
- Press ∧ or ∨ to scroll among the sub-menus, or to adjust a setting.
- without changing the current setting.
- Press ⊕ /EXIT to return to live video.


LCD display

Microphone

POWER

**TALK** 

# Overview - Parent unit



Arrow keys

VIEW /LCD ON/OFF

8 **◆ Volume ◆** 


11 Antenna


14 Power jack

12 RESET

13 Stand

# Overview - Baby unit





- Light sensor 2 Camera lens
- Microphone
- Night light
- On/Off switch
- On/Off LED light · On when the baby unit is turned on and is paired to the

unit is lost.

- parent unit. • Flashes when the baby unit is not being viewed or when the link to the parent
- 7 Light projection 8 Speaker
- rojection light on/off key 10 - Ö- Night light on/off key
- 11 Power jack 12 PAIR key
- 13 Slots for wall mounting

# Main menu icons

PARENT UNIT ICONS

Briahtness


 Adjust the parent unit's LCD brightness

Camera settings



Baby unit speaker volume Adjust the baby unit's speaker volume.





≋1≋2≋3≋4

 $\Pi_1\Pi_2\Pi_3\Pi_4\Pi_5$ · Select one of the five melodies.



60min 45min 30min 15min Set timer to stop playing the selected melody or soothing sound.







· Select one of the night light colours.

· Change to all seven colors in cycles.

menu

60min 30min 15min · Set timer to turn the night light off.

· Set to auto turn on the night light when baby unit detects sound. It will turn off after 15 minutes of no sound detection. Set **VOX sensitivity level** to detect sounds that only exceed certain levels. See **Sound sensitivity and** sound activation section for more ON/OFF



· Turn on/off the adaptive night light feature. When on, baby unit detects ambient light. If the room is bright the night light adjusts itself to be brighter; if the room is dim, the night light adjusts itself to be less bright



**Projection light** 

60min 45min 30min 15min · Set timer to turn the projection light off.


· Set to auto turn on the projection light when baby unit detects sound. It will turn off after 15 minutes of no sound detection. Set VOX sensitivity level to

Alert tones












Set the parent unit to beep



when the link between the parent unit and the baby unit

only detect sounds that exceed certain

Set the parent unit to beep


levéls. See **Sound sensitivity and** sound activation section for more.





**Temperature** 

Sound activation - screen and audio





■ Note



## PARENT UNIT ICONS (CONT'D)

# Status icons

### **Connection status**

- Till Strong signal strength. • Till - Moderate signal

Displays camera when baby


- T Low signal strength.
- T Weak signal strength. **Current view status**

### unit successfully linked to parent unit.

Night vision - On

**Zoom** - On

Lullaby - On



### Night light - Auto-on · Colour icon indicates the night light is set to auto-on, and is currently turned on by

sound activation. · Gray icon indicates the night light is currently off but is set to auto-on. Night light will turn on when sound is

detected by the baby unit.

- Projection light On
  - **Projection light** Auto on · Colour icon indicates the projection light is set to autoon, and is currently turned on by sound activation.
  - Gray icon indicates the rojection light is currently off but is set to auto-on. Projection light will turn on when sound is detected by

### Status icons

**°F** or **°C** 

### Real-time temperature

Temperature alert tone - On

• indicates low sound level

detected by the baby unit.

• IIII indicates moderate

• indicates high

Displays when the parent

• (IIII - battery is fully

needs charging.

level while adjusting.

• 🔲 - battery is low and

**Speaker volume** - displays the

parent unit speaker volume

animates when the battery is

unit speaker volume is set

sound level detected by the

sound level detected by the

(e.g. **57°F** or **14°C**).

9-level sound indicator

baby unit.

baby unit.

Mute alert

**Battery status** 

charging.

charged.

· Real-time temperature detected by the baby unit in Fahrenheit (°F) or Celsius (°C)



• Displays when connection between parent unit and baby unit is lost.

· Displays when parent unit's battery is low and needs charging.



**Alert icons** 

• Baby unit detects temperature reaches or exceeds the set maximum.



• Baby unit detects temperature is at or is lower than the set minimum.


# PROJECTION LIGHT

### · Displays when the parent

· The projection light located on the top of the baby unit projects a starry soft night light scene onto unit is talking to the baby sooth your baby to sleep. For optimal performance, place the baby unit in upright position.

# Optimal position

the ceiling with a tilting angle. Adjust your baby unit's position with the projection light to help



# NIGHT VISION

Adjust sound detection sensitivity

adjust the VOX sensitivity to detect sounds

and turn on the parent unit while its screen

screen will turn on and the baby unit starts

transmitting the sounds to the parent unit,

and you can see and hear your baby. If you

have turned on the **Night light Auto-on** 

and the Projection light Auto-on feature,

If you turn off **Sound activation**, you will

time, even when the parent unit screen is

hear sounds from the baby unit all the

they will turn on automatically to sooth

When the baby unit detects sounds that

exceed certain levels, the parent unit

You can turn on **Sound activation** and

is switched off or dimmed.

your baby.

switched off.



The baby unit has infrared LEDs that allow you to see your baby clearly at night or in a dark room. When the baby unit being viewed detects low light levels, the infrared LEDs are switched on automatically. The images from the baby unit are in black and white, and appears on the screen.

### ■ Notes

Sound sensitivity and sound activation

Level 5

(Highest)

The parent unit

screen and

speaker turn

on for very

small sounds,

including

background

baby's room.

Level 4

(High)

unit screen

and speaker

when your

soundly.

baby sleeps

turn on for soft

babbling and

louder sounds

The parent unit

(Default setting) | The parent

noises from your | remains quiet

Level 3

(Medium)

The parent unit

screen and

on for loud

speaker turns

babbling and

louder sounds

The parent unit | your baby.

from your baby. | from your baby. | sounds from

remains quiet

when your

baby makes

soft sounds.

Level 2

(Low)

The parent

unit screen

and speaker

The parent

unit remains

quiet when

your baby

makes soft

sounds.

for crying

Level 1

The parent

unit screer

and speake

turn on for

loud crying

or screechin

sounds from

your baby.

The parent

unit remains

quiet when

your baby

sounds.

makes soft

- It is normal if you see a short white glare on your parent unit screen as the baby unit
- adapts to the dark environmen When the infrared LEDs are on, the images are in black and white. This is normal.
- Depending on the surroundings and other interfering factors, like lightings, objects, colours and backgrounds, the video quality may vary. Adjust the baby unit angle or place the baby unit at a higher level to prevent glare and a blurry display

# DIM MODE

Dim mode helps you save parent unit power. Your parent unit display will dim automatically after 10 minutes of inactivity, when no keys are pressed or alerts are received from the baby unit.

Note
 Not
 Note
 Not
 Note
 Note
 Note
 Note
 Note
 Note
 Note

Sound activated screen and audio

off to save power when the baby unit detects no sound.

Once the baby unit detects sounds that are louder than the

speaker turn on automatically. The parent unit will then turn

If you have muted the parent unit speaker, only the parent unit

chosen sound sensitivity level, the parent unit screen and

off again after 50 seconds of no sound detection.

screen will turn on when a sound is detected.







### **❤** GENERAL PRODUCT CARE

To keep this product working well and looking good, follow these guidelines:

- · Avoid placing it near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps)
- When **Sound activation** is on, the parent unit screen remains • DO NOT expose it to direct sunlight or moisture.
  - · Avoid dropping the product or treating it roughly.
  - · Clean with a soft damp cloth.
  - · DO NOT immerse the parent unit and the baby unit in water and do not clean them under running water.
  - DO NOT use cleaning spray or liquid cleaners.
  - Make sure the baby unit and parent unit are dry before you connect them to the mains again.

### STORAGE

When you are not going to use the baby monitor for some time, store the parent unit, the baby unit and the adaptors in a cool and dry place

### **ADULT SUPERVISION**


- · This baby monitor should be for use by adults only.
- Do not place the baby unit inside the cot or playpen.
- · To ensure your children's safety, do not allow them to touch or play with the baby monitor and its accessories. THIS IS NOT A TOY.

# MOUNT THE BABY UNIT ON DRY WALL (OPTIONAL)


### ■ Notes


- Check for reception strength and camera angle before drilling the holes.
- The types of screws and anchors you need depend on the composition of the wall. You may need to purchase the screws and anchors separately to mount your camera units.
- Place the wall mount bracket on a wall and then use a pencil to mark two holes in parallel. Remove the wall mount bracket and drill two holes in the wall (5.5mm drill bit).


\_\_\_\_O




- 2. If you drill the holes into a stud, go to step 3.
- If you drill the holes into an object other than a stud, insert the wall anchors into the holes. Tap gently on the ends with a hammer until the wall anchors are flush with the wall.









- tighten the screws until only 6mm of the screws are exposed.
- mount bracket, and then slide it forward until it locks into place. Align the holes on the wall mount bracket with the screws on the wall, and slide the wall mount bracket down until it locks into place.








4. Place the camera unit on the wall



5. You can maximize your camera unit viewing angles by tilting the wall mount bracket. Hold the camera unit, and then rotate the knob in anticlockwise direction. This will loosen the joint of the wall mount bracket. Tilt your camera unit up or down to adjust to your preferred angle. Then, rotate the knob in clockwise direction to tighten the joint and secure the angle.



### CUSTOMER SERVICE AND PRODUCT WARRANTY

# vtech

### PRODUCT REGISTRATION

Visit www.vtech.co.uk/clubvtech/login to register your VTech product By joining the VTech Club you can also enter competition and out about news and events, seek expert advice for parents and let your kids play fun learning games and activities.



### PRODUCT WARRANTY

ank you for choosing this quality product from VTech.

- The product detailed above is covered by a one year warranty from the date of purchase against any defects in materials or workmanship The product may be returned to the place of purchase. Alternatively the product can be
- 3. VTech Electronics Europe Plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion

returned to VTech Electronics Europe Plc (see address below), with proof of purchase

- 4. If the product covered by this warranty is damaged due to misuse, modification or unauthorized repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void
- This warranty is personal to the original purchaser and is not transferable Breakages to the LCD screen are not covered by the warranty.
- Products returned to VTech Electronics Europe Plc, should be sent to the address show below and packed carefully to avoid damage in transit. Please do not include batteries adaptors. Please include details of the fault together with your name and address, contact phone number and/or email address
- To keep an online record of your warranty, please register your product online at

VTech Electronics Europe Plc, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, Nest Hallam, DE7 6HE THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

nis warranty is valid for the UK and Ireland only. For products purchased outside

### **IMPORTANT**

Please retain this booklet with your sales receipt as proof of the date of purchase. **Customer Service** 

Please call our Consumer Services Department on 03306 780149 (from UK) or +44 3306 780149 (outside UK) and a service representative will be happy to help you.

### DISPOSAL OF BATTERIES AND PRODUCT



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pn) set out in Battery Directive (2006/66/EC). The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

# **DECLARATION OF CONFORMITY**

This product is intended for use within Europe and UK.

This equipment complies with the essential requirements to EU's Radio Equipment Directive (2014/53/EU) and the UK's Radio Regulations 2017 on radio systems and telecommunication

VTech Telecommunications Ltd. hereby declares that

this Video Monitor VM5463 is in compliance with the essential requirements and other relevant provisions of EU's Radio Equipment Directive (2014/53/EÜ) and UK's Radio Equipment

The Declaration of Conformity for the VM5463 is available from www.vtechbabycare.com.

Manufacturer: VTech Telecommunications Ltd.

23/F., Tai Ping Industrial Centre, Block 1, 57 Ting kok Road, Tai Po, Hong Kong.

Importer: VTech Electronics Europe Plc Napier Court, Abingdon Science Park, Abingdon, Oxon, OX14 3YT, U.K.



