Video Monitor







Congratulations

on purchasing your new VTech product. Before using this HD video monitor, please read the Important safety instructions

/hat does this HD Video Monitor do?

VTech 5" Smart Wi-Fi 1080p Video Monitor allows you to stay close to your baby when you are on the move or away.

This monitor is Wi-Fi enabled, which uses your home wireless network to stream live video and audio through the HD baby unit and 5-inch colour screen parent unit. It allows you to maintain a constant connection to your baby.

You can also monitor from your smartphone and mobile tablet.

VTech 5" Smart Wi-Fi 1080p Video Monitor uses MyVTech Baby Pro app to let you instantly see and hear what's happening with your baby from anywhere in the world. Download the app at the App Store or the Google Play™ Store directly from your smartphone or mobile tablet

IMPORTANT SAFETY INSTRUCTIONS

When using your equipment, basic safety precaution should always be followed to reduce the risk of fire, electric

- shock and injury, including the following: Follow all warnings and instructions marked on the
- Adult setup is required. 3. CAUTION: Do not install the baby unit at a height above
- 4. This product is intended as an aid. It is not a substitute for responsible and proper adult supervision and should not be
- used as such. This product is not intended for use as a medical monitor. Do not use this product near water, for example, near to a
- bath, sink, swimming pool or shower. 7. CAUTION: Use only the battery provided. There may be a risk of explosion if a wrong type of battery is used for the parent unit. The battery cannot be subjected to high or low extreme temperature and low air pressure at high altitude during use, storage or transportation. Disposal of battery in fire or a hot oven, mechanically crushing or cutting the battery can result in an explosion. Leaving the battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid of gas. Battery subjected to extremely low air pressure may
- result in an explosion or the leakage of flammable liquid or gas. Dispose of used batteries according to the instructions. Use only the power adaptors included with this product. ncorrect power adaptor polarity or voltage can seriously damage the product.

Parent unit output: 5V DC 1A
VTech Telecommunications Ltd. Model: VT05EUS05100 (EU), VT05EUK05100 (UK). Baby unit output: 5V DC 1A.

VTech Telecommunications Ltd. Model: VT05EUS05100 (EU), VT05EUK05100 (UK). Rechargeable battery information: 3.8V 2100mAh Lithium-ion Polymer battery Zhongshan Tianmao Battery Co., Ltd. Model Number: BP1763

- 9. The power adaptors are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.
- 10. For pluggable equipment, the socket-outlet should be installed near the equipment and should be easily 11. Unplug this product from the wall outlet before cleaning.
- 12. Do not modify the power adaptors or replace with other adaptors, as this causes a hazardous situation.

13. Do not allow anything to rest on the power cords. Do not

- install this product where the cords may be walked on or 14. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home,
- consult your dealer or electricity supply provider. 15. Do not overload wall outlets or use an extension cord. 16. The equipment is to be supplied from an identified USB
- 17. Do not place this product on an unstable table, shelf, stand

port complying with the requirements of Limited Power

This product should not be placed in any area where proper ventilation is not provided. Slots and opening in the back or bottom of this product are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat source. . Never push objects of any kind into this product through

> 20. To reduce the risk of electric shock, do not is assemble his product, but take it to an authorised service acility. Disassembling or removing parts of the product other than via the battery door may expose you to dangerous voltages or other risks. Incorrect assembling can cause electric shock when the . You should test the sound reception every time you turn

the slots because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any

on the units or move one of the component Periodically examine all components for damage.

There is a very low risk of privacy loss when using certain electronic devices, such as baby monitors, cordless telephones, etc. To protect your privacy, make sure the product has never been used before purchase, reset the baby monitor periodically by powering off and then powering on the units, and power off the baby monitor if you are not intending to use it for some time. . The small parts of this monitor can be swallowed by

pabies or small children. Keep these parts out of reach 25. Children should be supervised to ensure that they do not play with the product.


 The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their

SAVE THESE INSTRUCTIONS

Use and store the product at a temperature between 0°C

- Do not expose the product to extreme cold, heat or direct unlight. Do not put the product close to a heating source. Batteries should not be exposed to excessive heat such as
- Mishandling batteries can cause burn, fire or explosion
- Warning–Strangulation Hazard– Children have STRANGLED in cords. Keep this cord out of the reach of children (more han 0.9m away. Do not remove warning bel on the adaptor cord. Never place the baby unit(s) inside the baby's crib or
- playpen. Never cover the baby unit(s) or parent unit with nything such as a towel or a blanket. Other electronic products may cause interference
- with your baby monitor. Try installing your baby monitor as far away from these electronic devices as possible: wireless routers, radios, cellular elephones, intercoms, room monitors, televisions personal computers, kitchen appliances and cordless

WHAT'S IN THE BOX




For mobile access:

MyVTech Baby Pro mobile app

Network	Wi-Fi
Wi-Fi router	2.4GHz 802.11 b/g/n
Internet connection	1.5 Mbps @ 720p or 2.5 Mbps @1080p upload bandwidth per baby unit





OVERVIEW

Baby unit overview

1 Light sensor

- Camera lens
- Microphone
- Infrared LEDs Allow you to see clearly in dark surroundings

- - Press to turn the night light on or off.

LED indicator

- Orange is steadily on when the baby unit is connecting to the parent unit in direct mode. Green is steadily on when the baby
- your home Wi-Fi network via the Wi-Fi Flashes orange slowly during video

unit and parent unit are connecting to

- streaming in direct mode.
- Flashes green slowly during video streaming via home Wi-Fi network.

ON


Power on/off switch.

- <u>Press and hold</u> for three seconds to
- · Reset the baby unit to factory default. 1. Press and hold PAIR key until you
- near a beep sound. 2. Release the **PAIR** key, and then press the **PAIR** key again five times until
- you hear another beep sound. 3. The baby unit will sound another beep when the reset completes. Then, the baby unit will reboot.

10 Night light

- Temperature sensor
- Slots for wall mounting
- Wall mount bracket is included in your package
- 13 **Power jack**

Parent unit overview



LINK LED light

- · On when the parent unit is linked to the baby unit
- · Flashes when the link to the baby unit

LED light

- On when the parent unit is connected to AC power, and the battery is charging.
- Flashes when the parent unit battery is low and needs charging.

3 3- level sound indicator light

- Green light is on when a low sound level is detected by the baby unit.
- Green and amber lights are on when a moderate sound level is detected by
- the baby unit. · Green, amber and red lights on when
- a high sound level is detected by the baby unit.

While in a submenu, press to view the

4 TALK / ♥

Press to zoom in/out.

• Press and hold to talk to the baby unit. • While in a submenu, press to exit.

- 14 Antenna
- 15 Stand



HOW THE SYSTEM WORKS

\$15 TIP For better security and more stable connectivity, this baby monitor requires connecting to a Wi-Fi network and operating in Router mode connection.


To set up Router mode, you must update the software, then go to

Configure Wi-Fi > Select Connection Mode, and choose Router mode.

Your baby monitor parent unit and baby unit connect to each other in Direct mode by default, which allows you to immediately stream video out of the box. It is NOT recommended to continue using Direct Mode connection after initial installation.

You may experience reduced signal strength if your





Router mode

You are required to set up your monitor streaming via your parent unit with an enhanced connection. Router mode is the recommended mode for stable connectivity.

Router mode uses your home Wi-Fi network to connect your video monitor. It supports live video streaming through the parent unit and smartphone app.

If you want to stream live video remotely with your mobile device, download and install the MyVTech Baby Pro mobile app. With the mobile app, your Wi-Fi router (not included) provides Internet connectivity to your HD video monitor system. It serves as a communicating channel between your baby unit and mobile device, allowing you to monitor and/or control your baby unit wherever you are. For more details, see **Download app for mobile access** section in this quick start guide.

Auto mode

■ Notes

Auto mode should only be used when your Wi-Fi router is periodically turned off or the Wi-Fi connection is unstable. It works by automatically selecting the connection mode (**Direct** or **Router**) when connecting to the baby unit(s). For routers turned on 24/7 with good Wi-Fi connectivity, **Router mode** is the best selection. Mobile app access will not be interrupted in **Auto mode**.

When both parent unit and app are viewing the camera simultaneously,

the video quality will be optimised to deliver the best possible viewing result.



Enhanced local access

PROTECT YOUR PRIVACY AND ONLINE SECURITY

VTech cares about your privacy and peace of mind. That's why we've put together a list of industry-recommended best practices to help keep your wireless connection private and your devices protected when online. We recommend you carefully review and consider complying with the following tips.

Ensure your wireless connection is secure. • Before installing a device, ensure your router's wireless signal is encrypted by selecting the "WPA2-PSK with AES" setting in your router's wireless security menu. Change default settings.

• Change your wireless router's default wireless network name (SSID) to something

- Change default passwords to unique, strong passwords. A strong password: - Is at least 10 characters long.
- Is complex
- Does not contain dictionary words or personal information.
- Contains a mix of uppercase letters, lowercase letters, special characters and numbers

Keep your devices up to date.

• Download security patches from manufacturers as soon as they become available. This will ensure you always have the latest security updates.

• If the feature is available, enable automatic updates for future releases. Disable Universal Plug and Play (UPnP) on your router. • UPnP enabled on a router can limit the effectiveness of your firewall by allowing

other network devices to open inbound ports without any intervention or approval from you. A virus or other malware program could use this function to compromise security for the entire network. For more information on wireless connections and protecting your data, please review

the following resources from industry experts: 1. Federal Communications Commission: Wireless Connections and Bluetooth Security

2. U.S. Department of Homeland Security: Before You Connect a New Computer to the

<u>www.fcc.gov/consumers/guides/how-protect-yourself-online</u>.

www.us-cert.gov/ncas/tips/ST15-003.


3. Federal Trade Commission: Using IP Cameras Safely https://www.consumer.ftc.gov/articles/0382-using-ip-cameras-safely.


4. Wi-Fi Alliance: Discover Wi-Fi Security http://www.wi-fi.org/discover-wi-fi/security.

CONNECT, CHARGE AND POWER ON THE BABY MONITOR

Connect the baby monitor

- **≅** Notes
- The rechargeable battery in the parent unit is built-in.
- Use only the power adaptors supplied with this product Make sure the parent unit and the baby unit are not connected to an electronically controlled electric outlet. Connect the power adaptors in a vertical or floor mount position only. The adaptors' prongs are not
- designed to hold the weight of the parent unit and the baby unit, so do not connect them to any ceiling under-the-table, or cabinet outlets. Otherwise, the adaptors may not properly connect to the outlets. Make sure the parent unit, the baby unit and the power adaptor cords are out of reach of children.






during normal operation.

Camera lens and surface may get warm

It will turn off after a while and stay off.






Charge the parent unit battery before use

The parent unit runs on rechargeable battery or AC power. To continuously monitor your baby, keep the parent unit connected to AC power. With the battery alone, the parent unit can cordlessly run for a short time only.

Notes

- · Before using the baby monitor for the first time, charge the parent unit battery for 12 hours. When the parent unit battery is fully charged, the battery icon becomes solid •••••.
- The standby time varies depending on your actual use


After the parent unit is fully charged, press **POWER** until the welcome screen appears.



The battery icon indicates the battery status (see the following table).

BATTERY INDICATORS	BATTERY STATUS	Action
The screen displays [1] and [1]. The light flashes.	The battery has very little power and may only be used for a short time.	Charge without interruption (about 30 minutes).
The battery icon becomes solid	The battery is fully charged.	To keep the battery charged, connect it to AC power when in use.





■ PARENT UNIT ICONS

Menu

Night light

 \oplus

 Select colour 1, 2 or 3. Turn off night light.


Melodies and soothing sounds



play one of the five melodies and five soothing sounds. You can also set the timer to stop lullaby playing after 15, 30 or 60

Select to play all melodies, or

minutes, or play non-stop. Alerts - Sound, motion and temperature



- Turn on/off sound detection and motion alerts. Select maximum and minimum
- temperature for alert range. • Turn on/off temperature alert.

Temperature format

Parent unit settings



- Adjust parent unit screen brightness. Turn on/off dim mode.
- Turn on/off Night Vision. Turn on/off baby unit's status LED.
- Update baby unit's security key.

General settings



Turn on/off Parent unit Wi-Fi

Connect to home Wi-Fi network.

- · Connect mobile phone.
- Turn on/off Low Battery Alert Tone. • Turn on/off No Link Alert Tone.
- Reset settings to factory default.



upward, rightward or downward.

MENU/SELECT Press to enter the main menu.

item, or save a setting.

• While in a menu, press to choose an


- Increase or decrease the parent unit's
- speaker volume. Microphone
- 11 POWER / LCD ON/OFF
- 12 Power jack
- Force reboot the parent unit.



The parent unit and baby unit connect to each other directly. Red bars indicate no connection

Router mode or

Auto mode on router connection The parent unit and baby unit connect via the Wi-Fi network. The red icon on the baby unit or parent unit, indicates



connect directly, while the baby unit and the app connect via home Wi-Fi network. The red icon on the left of the baby unit indicates no connection to the router. And red bars on the


right of the baby unit indicates no

connection between parent unit

and baby unit.


Sound detection alert is turned on.

Melodies and soothing sounds are turned on.




Parent unit speaker is muted.





Temperature alert is turned on.





Press **MENU** on the parent unit to enter the

main menu, choose a menu item, or save a

setting. You can use the parent unit menu for

play or stop lullaby, or adjust the motion and

advanced settings or operations, such as to

Press ∧, ∨, < or > to scroll among the

• Press TALK / to return to the live video.

Press -VOL / VOL+ to adjust your parent unit

speaker volume level received from the baby

If you plan to install your baby unit in a designated

which of your selected monitoring areas within the

house have good Wi-Fi signal strength. After you

have powered on your parent unit, you can use

your parent unit's Wi-Fi signal strength indicator

suitable location, you can install your baby unit.

Depending on surroundings and obstructing

Check with your parent unit again.

motors or fluorescent lamps).

• Clean with a soft damp cloth.

factors that affect signal strength, such as distance

Wi-Fi signal. To improve the Wi-Fi signal strength,

adjust the distance or direction of your parent unit.

GENERAL PRODUCT CARE

• DO NOT expose it to direct sunlight or moisture.

• DO NOT use cleaning spray or liquid cleaners.

• Clean the USB charging port of dust, dirt, and lint regularly.

· Avoid dropping the product or treating it roughly.

To keep this product working well and looking good, follow these guidelines:

and internal walls, you may experience reduced

the Wi-Fi router if needed.

Adjust the distance between your baby unit and

to assist in checking. Once you have identified the

location, and use your home Wi-Fi network to

connect your video monitor, you need to test

• Press to go to the **Help & info** page.

Press SELECT to select an item.

Use the menu

sound detection settings.

While in the menu:

menu options

Adjust speaker volume

After powering up your video monitor, the parent unit streams live video in direct mode.

with your monitor for functionality enhancements and mobile access. See Auto software

Press \oplus to zoom in or out.

We recommend you follow the instructions on screen to set up home Wi-Fi network

and firmware update and Download app for mobile access in this quick start guide.

Make sure your baby unit and parent unit are more than 1 metre apart; OR

1. Press **MENU** when the parent unit is idle.

monitor your areas remotely.

- > Connect Mobile Phone.
- 3. Scan the QR code in the parent unit to download the app into your mobile device
- 4. Follow the instructions in the mobile app to set up and pair your baby unit to the mobile app.

Alternatively, you can download the mobile app from the App Store or

Install MyVTech Baby Pro mobile app

- 1. Browse the App Store \bigcirc or the Google Play store \bigcirc .
- 2. Search for the mobile app with the keyword "MyVTech Baby Pro".
- 3. Download and install the MyVTech Baby Pro mobile app to your mobile device.

Scan the QR code on the right to get the app. ■Note

minimum requirement for the mobile app.






· Make sure your mobile device meets the

The mobile app is compatible with:

 Android[™] 6.0 or later; and iOS 12.0 or later.

Minimum requirement




1. Tap 🛂 to run the mobile app in your mobile device, and then create a user account.


After installing the mobile app, follow the instructions in the mobile app and parent

- 2. We recommend that you use common webmail services, such as Google Gmail, for the
- registration of your user account. Check your email (and Spam folder), and activate your new user account via the email link. Then, sign in to your account.
- 3. Follow the instructions in the mobile app to pair the camera. Tap =, then Add Camera in the mobile app to get started.

Talk to your baby via the baby unit 1. Press and hold the TALK key.







Adjust baby unit speaker volume


- 1. Press MENU.
- 4. Press < to decrease and ➤ to increase the baby unit's



Turn on/off the parent unit screen

Turn on or off the parent unit screen without powering off the parent unit. You will still hear sounds from the baby unit.


- Press POWER on the parent unit to turn off the screen.
- Press any key on the parent unit to turn the screen on again.



蒜 TIP

To restore to the default settings or reset the Wi-Fi connection, you can reset the parent unit by pressing the **RESET** key at the back of the unit.

Use a pin and insert it into the hole on the back of the parent unit, and then gently press the button inside.



Positioning the HD video monitor

This baby monitor should be for use by adults only.

· It is not a substitute for proper adult supervision, and should not be used as such.

For hearing protection, make sure the parent unit is more than 1 metre away from the baby

Increase the parent unit speaker volume if you cannot hear the sounds transmitted from the


noise stops. You can also press - **VOL** on the parent unit to lower or mute the noise.

unit. If you hear a feedback from the parent unit, move the parent unit further away until the

Testing the sound level of the HD video monitor

① CAUTION

- Keep the baby unit out of the reach of your baby. Never place or mount the baby unit inside the baby's cot or
- 1. Place the baby unit more than 1 metre away from



> 1 metre

2. Adjust the angle of the baby unit to aim at your baby




AUTO SOFTWARE AND FIRMWARE UPDATE

Connect your HD video monitor with home Wi-Fi network

3. To avoid causing a feedback from your HD video monitor:

Turn down the volume of your parent unit.

You must connect your video monitor to your secured home Wi-Fi network in order to receive the latest software and firmware updates. To set Wi-Fi up, go to:



Update the software

After connecting the system to your Wi-Fi network, the software will update every 4 hours. The Baby Unit will update automatically. The Parent Unit will prompt a message when the update is completed. Select "Now" to reboot the Parent Unit, or switch off and on the Parent Unit later to reboot the system into the latest software.

CUSTOMER SERVICE AND PRODUCT WARRANTY

PRODUCT WARRANTY Thank you for choosing this quality product from VTech

.The product detailed above is covered by a one year warranty from the date of purchase against any defects in materials or workmanship. The product may be returned to the place of purchase. Alternatively the product can be

without proof of purchase no replacement will be provided. VTech Electronics Europe Plc will examine the product and if it is found to be defectived ue to faulty materials or workmanship, will replace the product at their discretion.

4. If the product covered by this warranty is damaged due to misuse, modification or unauthorized repair, or because of faulty batteries, battery discharge or incorrect parts of the control of the cont electrical connections, then this warranty becomes void. 5. This warranty is personal to the original purchaser and is not transferable

6. Breakages to the LCD screen are not covered by the warranty roducts returned to VTech Electronics Europe Plc, should be sent to the address show

below and packed carefully to avoid damage in transit. Please do not include batteries adaptors. Please include details of the fault together with your name and address, contact phone number and/or email address 8. To keep an online record of your warranty, please register your product online at

VTech Electronics Europe Plc, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, West Hallam, DE7 6HE

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.


This warranty is valid for the UK and Ireland only. For products purchased outside the UK and Ireland, please contact your local distributor or place of purchase.

IMPORTANT

Please retain this booklet with your sales receipt as proof of the date of purchase.

Please visit www.vtechphones.eu to contact our Customer Service Department

DISPOSAL OF BATTERIES AND PRODUCT



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pn) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005. Help protect the environment by disposing of your product or batteries responsibly.

RM5754HD is in compliance with the essential requirements and other relevant provisions of EU's Radio Equipment Directive (2014/53/EU) and UK's Radio Equipment Regulations 2017. The Declaration of Conformity for the RM5754HD is available from

This equipment complies with the essential requirements to EU's Radio Equipment Directive (2014/53/EU) and the UK's Radio Regulations 2017 on radio systems and telecommunication

VTech Telecommunications Ltd. hereby declares that this 5" Smart Wi-Fi 1080p Video Monitor

CA

TECHNICAL SPECIFICATIONS

This product is intended for use within Europe and UK.

DECLARATION OF CONFORMITY

Frequency control	Crystal controlled PLL synthesizer
Transmit frequency	Baby unit: 2412 - 2472 MHz Parent unit: 2412 - 2472 MHz Maximum power used by the transmitter: 0.1W (100mW)
Channels	13
LCD	5" Colour LCD (IPS 1280x720 pixels)
Nominal effective range	Actual operating range may vary according to environmental conditions at the time of use.
Power requirements	Parent unit: 3.8V 2100mAh Li-ion battery Baby unit power adaptor: Output: 5V DC @ 1A Parent unit power adaptor: Output: 5V DC @ 1A

The Background Noise sound file was created by Caroline Ford, and is used under the Creative Commons license The Stream Noise sound file was created by Caroline Ford, and is used under the Creative Commons license. The Crickets At Night sound file was created by Mike Koenig, and is used under the Creative Commons license. The Heart Beat sound file was created by Zarabadeu, and is used under the Creative Commons license.

Android [™] and Google Play [™] are trademarks of Google Inc App Store is a trademark of Apple Inc., registered in the U.S. and other countries.

iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. Manufacturer: VTech Telecommunications Ltd.

23/F., Tai Ping Industrial Centre, Block 1, 57 Ting Kok Road, Tai Po, Hong Kong. Importer: VTech Electronics Europe Plc.

Napier Court, Abingdon Science Park, Abingdon, Oxon, OX14 3YT.

STORAGE

If the HD video monitor will not be used for an extended period of time, store the parent unit, the baby unit, and the adaptors in a cool, dry place.

Avoid placing it near heating appliances and devices that generate electrical noise (for example,

• DO NOT immerse the parent unit and the baby unit in water and do not clean them under running

• Make sure the parent unit and the baby unit are dry before you connect them to the mains again.

TEST THE LOCATION FOR THE BABY UNIT

MOUNT THE BABY UNIT (OPTIONAL)

Check for reception strength and camera angle of the baby unit before drilling the

The types of screws and wall plugs you need depend on the composition of the wall. You may need to purchase the screws and wall plugs separately to mount your baby units.

other screw in the top hole.

and a power supply.

3. Align the wall mount bracket and screws with

the holes in the wall as shown. Tighten the screw

in the middle hole first, so that the wall mount

bracket position is fixed. You can tighten the

4. Place the baby unit on the wall mount bracket,

Connect the power adaptor to the baby unit


and then slide it forward until it locks into place.

5. You can maximise your baby unit viewing angles by tilting the wall mount bracket.

1. Place the wall mount bracket on a wall and then use a pencil to mark two holes in parallel. Remove the wall mount bracket and drill two holes in the wall (5.5mm drill bit).

Hold the baby unit, and then rotate the knob in an anticlockwise direction. This will loosen the joint of the wall mount bracket.

Tilt your baby unit up or down to adjust to your preferred angle. Then, rotate the knob in a clockwise direction to tighten the



2. If you drill the holes into a stud, go • If you drill the holes into an

object other than a stud, insert the wall plugs into the holes. Tap gently on the ends with a hammer until the wall plugs are flush with the wall.

______ 3. Insert the screws into the holes and tighten the screws until only 6mm of the screws are exposed.

> 4. Place the baby unit on the wall mount bracket, and then slide it forward until it locks into place. Align the holes on the wall mount bracket with the screws on the wall, and slide the wall mount bracket down until it

