VM5463

Video Monitor

Full Color Pan and Tilt



vtech

Quick start guide



The Heart Beat sound tile was created by Larabadeu, and is used under the Creative Commons license. The Crickets At Night sound file was created by Mike Koenig, and is used under the Creative Commons license. The Stream Noise sound file was created by Caroline Ford, and is used under the Creative Commons license. The Background Noise sound file was created by Caroline Ford, and is used under the Creative Commons license,

ower requirements	Parent unit: 3.6V Ni-MH battery Baby unit power adapter: Output: 5V DC @ 1A Parent unit power adapter: Output: 5V DC @ 1A
Vominal effective range	Actual operating range may vary according to environmental conditions at the time of use.
rcp	S" Color LCD (WQVGA 480x272 pixel)
Channels	32
ransmit frequency	Baby unit: 2405 - 2475 MHz Parent unit: 2405 - 2475 MHz Maximum power used by the transmitter: 0.10W (100mW)
Frequency control	Crystal controlled PLL synthesizer

TECHNICAL SPECIFICATIONS

Zoom

Press \oplus to zoom in or out.

IMPORTANT SAFETY INSTRUCTIONS

When using your equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:

1. Follow all warnings and instructions marked on the

The applied nameplate is located at the bottom of the

- Adult setup is required.
- 3. CAUTION: Do not install the baby unit at a height above 2 metres.

 4. This product is intended as an aid. It is not a substitute for
- responsible and proper adult supervision and should not This product is not intended for use as a medical monitor. Do not use this product near water. For example, do not use it next to a bath tub, wash bowl, kitchen sink, laundry tub or swimming pool, or in a wet basement or
- CAUTION: Use only the battery provided. There may be a risk of explosion if a wrong type of battery is used for the parent unit. The battery cannot be subjected to high or low extreme temperature and low air pressure at high altitude during use, storage or transportation. Disposal of battery into fire or a hot oven, or mechanically crushing or cutting or the battery can result in an explosion. Leaving the battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid of as a Sattery subjected to extremely use in pressure may
- of gas. Battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas. Dispose of used battery according to the instructions. Use only the adapters included with this product. Incorrect adapter polarity or voltage can seriously damage the product.

Output: 5V DC 1A
Ten Pao Industrial Co.,Ltd.
Model: S005BNV0500100(EU); S005BNB0500100(UK).

Rechargeable battery information: YIYANG CORUN BATTERY CO., LTD. NIMH AAA900mAh 3.6V

- The power adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet
- For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily Unplug this product from the wall outlet before cleaning.
- for cleaning.

 12. Do not cut off the power adapters to replace them with other plugs, as this causes a hazardous situation.

not use liquid or aerosol cleaners. Use a damp cloth

- Do not allow anything to rest on the power cords. Do not install this product where the cords may be walked on or 14. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home,
- consult vour dealer or local power company. Do not overload wall outlets or use an extension cord Do not place this product on an unstable table, shelf, stand or other unstable surfaces.
- 17. This product should not be placed in any area where proper ventilation is not provided. Slots and openings in the back or bottom of this product are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat
- 18. Never push objects of any kind into this product through the slots because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.

- 19. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing parts of the product other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the product is subsequently used.
- 20. You should test the sound reception every time you turn on the units or move one of the components. Periodically examine all components for damage.
- There is a very low risk of privacy loss when using certain electronic devices, such as baby monitors, cordless telephones, etc. To protect your privacy, make sure the product has never been used before purchase, reset the baby monitor periodically by powering off and then powering on the units, and power off the baby monitor if you will not use it for some time.
- 23. Children should be supervised to ensure that they do not play with the product.
- The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. SAVE THESE INSTRUCTIONS

- Use and store the product at a temperature between $0^{\circ}C$ and $40^{\circ}C$. Do not expose the product to extreme cold, heat
- or direct sunlight. Do not put the product close to a heating source. Batteries should not be exposed to excessive heat such s bright sunshine or fire.
- Warning-Strangulation Hazard-Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3 ft (0.9 m) away). Do not remove this
- Never place the baby unit(s) inside the baby's cot or playpen. Never cover the baby unit(s) or parent unit with anything such as a towel or a blanket.
- Other electronic products may cause interference with your baby monitor. Try installing your baby monitor as far away from these electronic devices as possible: wireless routers, radios, cellular telephones, intercoms, room monitors, televisions, personal computers, kitchen appliances and conducts telephones.

Precautions for users of implanted cardiac pacemakers Cardiac pacemakers (applies only to digital cordless


Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the interference between portable wireless devices and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicians

Should keep wireless devices at least six inches from the

- Should NOT place wireless devices directly over the cemaker, such as in a breast pocket, when it is turned
- WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless devices

Electromagnetic fields (EMF) This VTech product complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user's manual, the product is safe to be used based on scientific evidence


WHAT'S IN THE BOX



CONNECT THE BABY MONITOR


■NOTES

- The rechargeable battery in the parent unit is built-in. Use only the power adapters supplied with this product
- Make sure the baby monitor is not connected to a switch-controlled electric outlet.
- Connect the power adapters in a vertical or floor mount position only. The adapters' prongs are not designed to hold the weight of baby monitor, so do not connect them to any ceiling, under-the-table, or cabinet outlets. Otherwise, the adapters may not properly connect to the outlets.
- Make sure the parent unit, the baby units and the power adapter cords are out of reach of children.



POWER ON OR OFF THE BABY MONITOR Slide the switch to power on or off your baby unit. Press and hold POWER to power on or off your parent unit. **LINK** POWER Power on

POSITIONING THE BABY MONITOR



Note
 Not
 Note
 Not
 Note
 Note
 Note
 Note
 Note
 Note
 Note

4 STATUS CHECK

① CAUTION

Once you power on both your baby unit and parent unit, your parent unit displays image from the baby unit, and the **LINK** LED light turns on

The **ON** LED light of baby unit turns on.



Turn on/off temperature alert tone.

whenever the room temperature

outside of the set temperature range

detected by the baby unit falls

Set the minimum temperature.

· Set the maximum temperature.

• Set temperature display in

Set sound activation on or off.

of no sound detection.

turn on for 10 seconds.

· When it is on, and the baby unit

detects no sound, the parent unit

a sound is detected, the parent

unit screen and speaker turns on

screen stays off to save power. Once

automatically, and you can see and

hear your baby. The parent unit will

then turn off again after 50 seconds

• When the parent unit screen is off

and it receives alerts, for example,

parent unit screen and speaker will

link lost between parent unit and

baby unit, or battery is low, the

You can set VOX sensitivity level

ON/OFF Turn on/off sound activation

NOTE

Set the parent unit to beeps

To avoid interference from other electronic

devices, place your baby monitor at least 3 feet

routers, microwaves, cell phones and computers.

(1 metre) away from devices such as wireless

Basic operation - Parent unit

Adjust speaker volume


Press ● VOL / VOL ● to adjust your parent unit speaker volume.



Turn off the screen

Press and hold TALK and speak to your parent unit. Your voice is transmitted to the baby unit. Release **TALK** when finish talking and hear your baby again.

Talk to your baby unit



Press and hold LCD ON/OFF to switch off

the screen. You can still hear sound from the baby unit.



• Press any keys on the parent unit to turn on the screen again.

Use the menu

Press $\frac{MENU}{SELECT}$ to enter the menu, choose a menu item, or save a setting. You can use the parent unit for advanced settings or operations, such as to play or stop the baby unit lullaby, or to adjust the baby unit sound sensitivity.

While in the menu:


LCD display

Microphone


POWER

TALK

- Press MENU SELECT to select an item, or to save a setting.
- Press ∧ or ∨ to scroll among the sub-menus. or to adjust a setting.
- without changing the current setting.
- Press ♠ /EXIT to return to live video.



Overview - Parent unit



Arrow keys

VIEW /LCD ON/OFF

8 **◆ Volume ◆**


11 Antenna

12 RESET

14 Power jack

13 Stand

Overview - Baby unit



- Light sensor
 - Camera lens
 - Microphone Night light
 - On/Off switch

parent unit.

- On/Off LED light · On when the baby unit is
- Flashes when the baby unit is not being viewed; or when the link to the parent unit is lost.

turned on and is paired to the

- Light projection Speaker
- ★ Projection light on/off key 10 - O- Night light on/off key
- 11 Power jack
- 13 Slots for wall mounting

PARENT UNIT ICONS

Main menu icons **Brightness** Adjust the parent unit's LCD brightness

Camera settings



Baby unit speaker volume · Adjust the baby unit's speaker volume.

Lullaby





• Select one of the soothing sounds,





selected melody or soothing sound.

Night light

ON / OFF Turn on/off night light

· Select one of the night light colors.

60min 45min 30min 15min · Set timer to turn the night light off.

 Set to auto turn on the night light when baby unit detects sound. It will turn off after 15 minutes of no sound detection. You can set **VOX sensitivity level** to detect sounds that exceed certain levels. See **Sound sensitivity** and sound activation section.



60min 45min 30min 15min · Set timer to turn the projection light





· Set to auto turn on the projection light when baby unit detects sound. It wi turn off after 15 minutes of no sound detection. You can set VOX sensitivity **level** to detect sounds that exceed certain levels. See Sound sensitivity and sound activation section.

Alert tones









ON/OFF

on or off when selecting an option in the menus.



activation section.











Projection light

















• Turn on/off the alert vibration.



Temperature

Sound activation - screen and audio

VOX (Voice Activated Alert) Sensitivity

to activate parent unit screen and sound when baby unit detects sounds that exceed certain levels. See Sound sensitivity and sound

PARENT UNIT ICONS (CONT'D)

Status icons **Connection status**

• Till - Strong signal strength.

• Till - Moderate signal • T - Low signal strength.

 T - Weak signal strength. **Current view status**

Displays camera when baby unit successfully linked to parent unit.

Night vision - On

Zoom - On

Lullaby - On

Night light - On

Night light - Auto-on Color icon indicates the night light is set to auto-on, and is

activation Gray icon indicates the night light is currently off but is set to auto-on. Night light will turn on when sound is detected by the baby unit.

currently turned on by sound



Projection light - Auto on Color icon indicates the projection light is set to autoon, and is currently turned on by sound activation.

 Gray icon indicates the rojection light is currently off but is set to auto-on. Projection light will turn on when sound is detected by

Status icons

Real-time temperature

(e.g. **57°F** or **14°C**).

9-level sound indicator

baby unit.

baby unit.

Mute alert

Battery status

charging.

charged.

Alert vibration - On

· Real-time temperature

detected by the baby unit in

Fahrenheit (°F) or Celsius (°C)

Temperature alert tone - On

• indicates low sound level

detected by the baby unit.

• IIII indicates moderate

• indicates high

Displays when the parent

Displays when the parent

r> ••• > ••• > ••• 7

• (IIIII) - battery is fully

needs charging.

level while adjusting.

Speaker volume - displays the parent unit speaker volume

unit speaker volume is set

unit is talking to the baby

animates when the battery is

sound level detected by the

sound level detected by the

°F or **°C**

· Displays when parent unit's battery is low and needs charging.



• Displays when connection between parent unit and baby unit is lost.



Alert icons


• Baby unit detects temperature reaches or exceeds the set maximum.




• Baby unit detects temperature is at or is lower than the set minimum.

PROJECTION LIGHT

· The projection light located on the top of the baby unit projects a starry soft night light scene onto the ceiling with a tilting angle. Adjust your baby unit's position with the projection light to help sooth your baby to sleep. For optimal performance, place the baby unit in upright position.





Level 4

unit screen

and speaker

remains auiet

when your

baby sleeps

soundly.

turn on for soft on for loud

(High)

(Default setting) | The parent

Level 3

screen and

babbling and babbling and for crying

louder sounds | louder sounds | and louder

The parent unit | The parent unit | your baby.

when your

baby makes

soft sounds.

remains quiet

speaker turns

The parent unit | The parent

from your baby. from your baby. sounds from sounds from

unit screen

The parent

your baby

makes soft

sounds.

unit remains

turn on



Adjust sound detection sensitivity

adjust the VOX sensitivity to detect sounds

and turn on the parent unit while its screen

screen will turn on and the baby unit starts

transmitting the sounds to the parent unit,

and you can see and hear your baby. If you

have turned on the **Night light Auto-on**

and the Projection light Auto-on feature,

If you turn off **Sound activation**, you will

time, even when the parent unit screen is

hear sounds from the baby unit all the

NIGHT VISION

they will turn on automatically to sooth

When the baby unit detects sounds that

exceed certain levels, the parent unit

You can turn on **Sound activation** and

is switched off or dimmed.

your baby.

switched off.

The baby unit has infrared LEDs that allow you to see your baby clearly at night or in a dark room. When the baby unit being viewed detects low light levels, the infrared LEDs are switched on automatically. The images from the baby unit are in black and white, and appears on the screen.

Level 5

(Highest)

The parent unit

screen and

speaker turn

small sounds,

background

baby's room.

noises from your

on for very

including

■ Notes

Sound sensitivity and sound activation

- It is normal if you see a short white glare on your parent unit screen as the baby unit is
- adapting to the dark environmer When the infrared LEDs are on, the images are in black and white. This is normal.
- Depending on the surroundings and other interfering factors, like lightings, objects, colors and backgrounds, the video quality may vary. Adjust the baby unit's angle or place the baby unit at a higher level to prevent glare and blurry display.

DIM MODE

The parent

unit screen

turn on for

loud crvina

or screeching

vour baby.

The parent

vour baby

makes soft

sounds.

unit remains

and speaker and speaker

auiet when auiet when

The parent unit display will dim to conserve energy after 10 minutes of inactivity, in which there is neither key pressed nor alert received from the baby unit.

₿Note

Sound activated screen and audio

to save power when the baby unit detects no sound.

off again after 50 seconds of no sound detection.


screen will turn on when a sound is detected.

Once the baby unit detects sounds that are louder than the

speaker turn on automatically. The parent unit will then turn

If you have muted the parent unit speaker, only the parent unit

chosen sound sensitivity level, the parent unit screen and



❤ GENERAL PRODUCT CARE

To keep this product working well and looking good, follow these guidelines:

- · Avoid putting it near heating appliances and devices that generate electrical noise (for example, motors or
- fluorescent lamps)
- When Sound activation is on, the parent unit screen stays off • DO NOT expose it to direct sunlight or moisture.
 - · Clean with a soft cloth.
 - · DO NOT immerse the parent unit and the baby unit in water and do not clean them under the tap
 - DO NOT use cleaning spray or liquid cleaners.

· Avoid dropping the product or treating it roughly.

• Make sure the baby unit and parent unit are dry before you connect them to the mains again.

STORAGE

When you are not going to use the baby monitor for some time, store the parent unit, the baby unit and the adaptors in a cool and dry place

ADULT SUPERVISION


- This baby monitor should be used as an aid and proper adult supervision is required.
- Do not place the baby unit inside the cot or playpen.
- · As for children's safety, touch or play with the baby monitor and all the accessories are not allowed. THIS IS

MOUNT THE BABY UNIT ON DRY WALL (OPTIONAL)


■ Notes


- Check for reception strength and
- camera angle before drilling the holes. The types of screws and anchors you need depend on the composition of the wall. You may need to purchase the screws and anchors separately to mount your camera units.
- Place the wall mount bracket on a wall and then use a pencil to mark two holes in parallel. Remove the wall mount bracket and drill two holes in the wall (7/32 inch drill bit).

____O





- 2. If you drill the holes into a stud, go to step 3.
- If you drill the holes into an object other than a stud, insert the wall anchors into the holes. Tap gently on the ends with a hammer until the wall anchors are flush with the wall.






3. Insert the screws into the holes and tighten the screws until only 1/4 inch of the screws are exposed.





5. You can maximize your camera unit's viewing angles by tilting the wall mount bracket. Hold the camera unit, and then rotate the knob in anticlockwise direction. This will loosen the joint of the wall mount bracket. Tilt your camera unit up or down to adjust to your preferred angle. Then, rotate the knob in clockwise direction to tighten the joint and secure the angle.



CUSTOMER SERVICE AND PRODUCT WARRANTY

PRODUCT WARRANTY

Thank you for choosing this quality product from VTech. imaginative play and learning

- The product detailed above is covered by a one year warranty from the date of purchase against any defects in materials or workmanship
- The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase without proof of purchase no replacement will be provided. VTech Electronics Europe plc will examine the product and if it is found to be defective
- due to faulty materials or workmanship, will replace the product at their discretion If the product covered by this warranty is damaged due to misuse, modification o unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
- . This warranty is personal to the original purchaser and is not transferable
- . Breakages to the LCD screen are not covered by the warranty.
- Returns to VTech Electronics Europe plc should include a cheque or postal order for
- Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor). Please include details of the fault together with your name and address. 9. To keep an online record of your warranty, please register your product online at www.
- Vtech Electronics EU PLC, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, West

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT

his warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase


Please retain this booklet with your sales receipt as proof of the date of purchase. **Customer Service**

Please call our Consumer Services Department on 03306 780149 (from UK) or +44 3306 780149 (outside UK) and a service representative will be happy to help you.

DISPOSAL OF BATTERIES AND PRODUCT



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.





This product is intended for use within Europe and UK.

DECLARATION OF CONFORMITY

This equipment complies with the essential requirements to EU's Radio Equipment Directive (2014/53/EU) and the UK's Radio Regulations 2017 on radio systems and telecommunication

VTech Telecommunications Ltd. hereby declares that

this Video Monitor VM5463 is in compliance with the essential requirements and other relevant provisions of EU's Radio Equipment Directive (2014/53/EÜ) and UK's Radio Equipment

The Declaration of Conformity for the VM5463 is available from www.vtechbabycare.com.

Manufacturer: VTech Telecommunications Ltd. 23/F., Tai Ping Industrial Centre, Block 1, 57 Ting kok Road, Tai Po, Hong Kong.

Importer: VTech Electronics Europe plc Napier Court, Abingdon Science Park, Abingdon, Oxon, OX14 3YT, U.K.

