BM1000

Digital Audio Monitor




vtech


User's manual

CONGRATULATIONS


on purchasing your new VTech product. Before using this product, please read Important safety instructions

This manual has all the feature operations and troubleshooting necessary to install and operate your new VTech product. Please review this manual thoroughly to ensure proper installation and operation of this innovative and feature-rich VTech product.





Ż



TECHNICAL SPECIFICATIONS

IMPORTANT SAFETY INSTRUCTIONS

20.

23.

25.

2.

3.

The applied nameplate is located at the bottom of the baby unit's base. When using your equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following: 1. Follow all warnings and instructions marked on the

- product. Adult setup is required. CAUTION: Do not install the baby unit at a height above 3.
- his product is intended as an aid. It is not a substitute 4
- for responsible and proper adult supervision and should not be used as such.
- This product is not intended for use as a medical 5. 6.
- Do not use this product near water. For example, do not ise it next to a bath tub. wash bowl, kitchen sink, laundry use it next to a bath tub, wash bowl, kitchen sink, laundry tub or swimming pool, or in a wet basement or shower. CAUTION: Use only the battery provided. There may be a risk of explosion if a wrong type of battery is used for the parent unit. The battery cannot be subjected to high or low extreme temperature and low air pressure at high altitude during use, storage or transportation. Disposal of battery into fire or a hot oven, or mechanically crushing or cutting or the battery can result in an explosion. Leaving the battery in an extremely high temperature. Leaving the battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid of gas. Battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas. Dispose of used battery according to the instructions.
- Use only the adapters included with this product. Incorrect adapter polarity or voltage can seriously damage the product.


Output: 6V DC 450mA Ten Pao Industrial Co.,Ltd. Model: S003ATV0600045(EU), S003ATB0600045(UK).

Rechargeable battery information: 2 x 1.2V AAA size 400mAh NiMH Corun : NIMH AAA 400mAh 1.2V

- The power adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet
- For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible
- Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
 Unplug the power cords before replacing battery. 11.
- Do not cut off the power adapters to replace them with other plugs, as this causes a hazardous situation.
 Do not allow anything to rest on the power cords. Do not install this product where the cords may be walked on or crimped
- This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home, consult your dealer or local power company.
- Do not overload wall outlets or use an extension cord 17. Do not place this product on an unstable table, shelf, 18.
- stand or other unstable surfaces. This product should not be placed in any area where proper ventilation is not provided. Slots and openings in the back or bottom of this product are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat register
- Never push objects of any kind into this product through the slots because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product. 19.

BEFORE USE

NOTE 1



O

 \bigcirc

 \bigcirc

Π

3ft (1m

0

Test your baby monitor

You may test the baby monitor before initial use,

- and at regular times thereafter. () CAUTION • For hearing protection, make sure the parent unit is more than 1 metre away from the baby unit. If you hear any high-pitched noise, move the parent unit further until the noise stops. You can also press ▼
- on the parent unit to lower or mute the noise
- 1. Make sure your baby unit and parent unit are on.
- 2. Speak towards the microphone of the baby unit. You will hear the sound at the parent unit, and see the visual sound indicators light up.
- NOTE 🗄 • When the **POWER** LED light flashes, move the parent unit closer to the baby unit (observe the minimum distance of 1 metre). You can also check if the baby unit is connected to a live power socket and switched on.

尝TiP

 Increase the speaker volume of the parent unit if you cannot hear the sounds transmitted from the papy unit.


Positioning the baby monitor

() CAUTION

- Keep the baby unit out of the reach of your baby. Never place or mount the baby unit inside the baby's cot or playpen.
- 1. Place the baby units more than 1 metre away from your baby.
- 2. Place the parent unit more than 1 metre away from the baby unit to avoid screeching noise.

() CAUTION

- The default volume of your parent unit is level 3, and the maximum volume is level 5. If you experience high-pitched screeching noise from your baby monitor while positioning: - Make sure your baby units and parent unit are more than
- 1 metre apárt, OR - Turn down the volume of your parent unit.



Children should be supervised to ensure that they do not play with the product. The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

SAVE THESE INSTRUCTIONS Cautions

To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing parts of the product other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the product is subsequently used. You should text the sound reception every time you to

You should test the sound reception every time you turn on the units or move one of the components.
 Periodically examine all components for damage.

There is a very low risk of privacy loss when using certain electronic devices, such as baby monitors, cordless telephones, etc. To protect your privacy, make sure the product has never been used before purchase, reset the baby monitor periodically by powering off and then powering on the units, and power off the baby monitor if you will not use it for some time.

- Use and store the product at a temperature between 0°C and 40°C. Do not expose the product to extreme cold, heat or direct sunlight. Do not put the product close to a heating
- ource. Batteries should not be exposed to excessive heat such as bright sunshine or fire.
- Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3 ft (0.9m) away). Do not remove this tag. Never place the baby unit(s) inside the baby's cot or playpen. Never cover the baby unit(s) or parent unit with anything such as a towel or a blanket. 4.
- 6.
- Other electronic products may cause interference with your baby monitor. Try installing your baby monitor as far away from these electronic devices as possible: wireless routers, radios, cellular telephones, intercoms, room monitors, televisions, personal computers, kitchen appliances and cordless telephones.

Precautions for users of implanted cardiac pacemakers Cardiac pacemakers (applies only to digital cordless devices): Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the interference between portable wireless devices and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicia

Pacemaker patients

 Should keep wireless devices at least six inches from the pacemaker. Should NOT place wireless devices directly over the pacemaker, such as in a breast pocket, when it is turned

WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless devices.

Electromagnetic fields (EMF) This VTech product complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user's manual, the product is safe to be used based on scientific evidence ailable today

Power on or off the parent unit


- <u>Press and hold</u> \oplus to turn on the parent unit. The **POWER** LED light turns on.
- <u>Press and hold</u> \oplus again to turn off the parent unit. The **POWER** LED light turns off.

level

NOTE

- Press ▼ repeatedly until the volume reaches the minimum.
- • When the parent unit is in mute, the visual sound indicator will still indicate the sound detected from the baby unit.





CONNECT

Install the parent unit battery


The package comes with two rechargeable batteries. You can power up the parent unit by using the two rechargeable batteries or by connecting it to the mains power. However, even if the parent unit is connected to the mains power, we recommend that you also install the rechargeable batteries. This guarantees the continual operation in case of a power outage.

• Use only the batteries supplied with this product. • If the parent unit will not be used for a long time, disconnect and remove the batteries to prevent possible leakage.

- 1. Remove the battery compartment cover.
- 2. Install the supplied rechargeable batteries into the battery compartment, matching the polarity markings (+ and -). 3. Close the battery compartment cover.

Connect the baby monitor

- Use only the power adapters supplied with this product.
- · Make sure the baby monitor is not connected to a switch controlled electric outlet.
- · Connect the power adapters in a vertical or floor mount position only. The adapters' prongs are not designed to hold the weight of baby monitor, so do not connect them to any ceiling, under-the-table, or cabinet outlets. Otherwise, the adapters may not properly connect to the outlets.
- Make sure the parent unit, the baby unit and the power adapter cords are out of reach of children. · With audio reminder feature preset to on, the parent unit plays an audio reminder when it is connected to a baby unit.



Using the baby monitor

Power on or off the baby unit


- <u>Press and hold</u> \oplus to turn on the baby unit. The **POWER** LED light turns on.
- Press and hold \oplus again to turn off the baby unit. The **POWER** LED light turns off.

Adjust parent unit speaker volume


- The speaker volume is preset to level 3, and the maximum volume is level 5. You can adjust it to your preferred volume
- Press ▲ or ▼ on the parent unit to adjust the speaker volume.
- If you continue to press \blacktriangle or \blacktriangledown when the volume reaches the minimum or maximum setting, the parent unit will beep twice.

To mute the speaker volume:

• To unmute, press ▲ repeatedly until it reaches your desired volume.



Parent unit overview



1 Visual sound indicators 0 0 0 0 0 The visual sound indicators can show the sound level detected by the

speaker volume setting.

Sound level detected by the baby unit

baby unit or the volume level during

- • • • One to three green lights indicate a moderate sound level detected by the baby unit.
- • • • Additional red lights indicate a higher sound level detected by the baby unit (e.g. baby crying loudly).

Speaker volume level

- • • • One to three green lights indicate Level 1 to Level 3 of the speaker volume settina.
- $\cdot \circ \circ \circ \bullet \bullet$ Additional red lights indicate Level 4 to Level 5 of the speake volume setting.

BABY UNIT OVERVIEW

1 POWER light vtech (1)(2)2 (3)(4)3

■ PARENT UNIT ALERT TONES

Low battery tone

• Beeps twice every 10 minutes when the battery is low.

unit is out of range from the baby unit.

4

- Out of range tone
- Beeps three times every 30 seconds when there is no link

between the baby unit and parent unit, or when the parent

• On when the baby unit is

• Flashes when the link to the

• Press and hold to turn on or off

powered up.

也 (On/off)

Microphone

Power jack

parent unit is lost.

the baby unit.

✓ GENERAL PRODUCT CARE

- To keep this product working well and looking good, follow these guidelines: · Avoid putting it near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose it to direct sunlight or moisture.
- Avoid dropping the product or treating it roughly.
- Clean with a soft cloth. • DO NOT immerse the parent unit and the baby unit in water and do not clean them under the tap.
- DO NOT use cleaning spray or liquid cleaners.
- Make sure the baby unit and parent unit are dry before you connect them to the mains again.

STORAGE

When you are not going to use the baby monitor for some time, store the parent unit, the baby unit and the adapters in a cool and dry place.

CUSTOMER SERVICE AND PRODUCT WARRANTY

PRODUCT WARRANTY ONE YEAR Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning. CTWAP . The product detailed above is covered by a one year warranty from the date of purchase against any defects in materials or workmanship. 2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase without proof of purchase no replacement will be provided. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion. 4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void. 5. This warranty is personal to the original purchaser and is not transferable. 6. Breakages to the LCD screen are not covered by the warranty. 7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor). Please include details of the fault together with your name and address. 9. To keep an online record of your warranty, please register your product online at www vtech.co.uk/warranty Vtech Electronics EU PLC, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, West Hallam, DE7 6HE THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

receipt as proof of the date of purchase.

Customer Service Please call our Consumer Services Department on 03306 780149 (from UK) or +44 3306 780149 (outside UK) and a service representative will be happy to

DECLARATION OF CONFORMITY

This product is intended for use within Europe and UK. This equipment complies with the essential requirements to EU's Radio Equipment Directive (2014/53/EU) and the UK's Radio Regulations 2017 on radio systems and telecommunication equipment.

Vtech Telecommunications Ltd. hereby declares that this Audio Monitor BM1000 is in compliance with the essential requirements and other relevant provisions of EU's Radio Equipment Directive (2014/53/EU) and UK's Radio Equipment Regulations 2017.

The Declaration of Conformity for the BM1000 is available from www.vtechbabycare.com.

Manufacturer: VTech Telecommunications Ltd.

23/F., Tai Ping Industrial Centre, Block 1, 57 Ting kok Road, Tai Po, Hong Kong. Importer: VTech Electronics Europe plc

Napier Court, Abingdon Science Park, Abingdon, Oxon, OX14 3YT, U.K.

Q_{&A}

Why doesn't the light on the bab when I switch or Why doesn't th light on the par turn on when I the units?

Why does the k monitor not res normally?

Why does the k monitor produ high-pitched no Why does the p

beep?

Why don't I hea Why can't I hear cry?

Why does the **C** light on the par flash?

Why can't I esta connection? W connection lost and then? Why sound interrupt



This warranty is valid for the UK and Eire only. For products purchased outsid the UK and Eire, please contact your local distributor or place of purchase

IMPORTANT Please retain this booklet with your sales

POWER

 \square

the baby unit.

CHARGING

low.

じ(On/off)

Speaker

Belt clip

10 Power jack

parent unit.

▲ (Volume up)

speaker volume.

Battery compartment cover

4

5

6

7

8

9

unit is charging.

▼ (Volume down)

speaker volume.

• Lights on steadily in green when

• Flashes in green when there is no

link between the baby unit and

parent unit, or when the parent unit

is out of range from the baby unit.

· Steady on in red when the parent

• Flashes in red when the battery is

• Press to decrease the parent unit

• Press and hold to turn on or off the

• Press to increase the parent unit

the parent unit is on and linked to

help you.





The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains

more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pn) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005. Help protect the environment by disposing of your product or batteries responsibly.

FREQUENTLY ASKED QUESTIONS

Below are the questions most frequently asked about the baby monitor

| questions most trequently asked about the baby monitor. | |
|------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ne POWER by unit turn on on the units? | Perhaps the baby unit is not connected to the power supply. Connect the baby unit to power supply. The baby unit turns on. |
| he POWER arent unit I switch on | Perhaps the batteries of the parent unit are depleted and the parent unit is not connected to power supply. Connect the parent unit to power supply and charge the parent unit's batteries. The parent unit turns on and establishes connection with the baby unit. |
| baby sspond | Try the following (in the order listed) for common cure: 1. Disconnect the power to the baby unit and the parent unit. 2. Remove the batteries from the parent unit. 3. Connect the baby unit to the power supply again. The baby unit turns on. 4. Connect the parent unit to the power supply again. The parent unit turns on. 5. Wait for the parent unit to synchronize with the baby unit. Allow up to one minute for this to take place. 6. Press ▲ or ▼ to adjust the speaker volume on the parent unit. |
| baby uce a noise? | The parent unit and baby unit may be too close to each other. Move the parent unit away from the baby unit until the noise stops; OR Turn down the volume of your parent unit. |
| parent unit | The parent unit beeps three times every 30 seconds when the baby unit is out of range. Move the parent units closer to the baby unit (but not less than 1 metre). |
| | The parent unit may not have enough charge for the parent unit to perform normally. Charge the battery in the parent unit for at least 30 minutes. |
| ear a sound/ ar my baby | Make sure that both baby unit and parent unit are on. If you see the visual sound indicators light up, but there is no sound, then you may have muted the volume or set it to a lower level. Adjust the volume to a higher level. |
| | If the visual sound indicators do not light up, and you cannot hear any sound, it is because the sound is too low for the baby unit to detect. This is normal. Place the baby unit at least 1 metre away from your baby. |
| CHARGING arent unit | If the parent unit is powered by batteries, the parent unit beeps twice every 10 minutes and the CHARGING light flashes in red when the battery is low. Connect the parent unit to the power supply and charge the battery for at least 30 minutes. |
| tablish a Vhy is the t every now y are there ptions? | The baby unit may be out of range. Move the parent units closer to the baby unit (but not less than 1 metre). |
| | Other electronic products may cause interference with your baby monitor. Try installing your baby monitor as far away from these electronic devices as possible. |